
Programmer's Quick Reference Guide

Publication number 54542-97042
First edition, November 1995

For Safety information, Warranties, and Regulatory
information, see the pages at the end of this book.

© Copyright Hewlett-Packard Company 1993-1995
All Rights Reserved

HP 54520C and 54540C Series Oscilloscopes

Introduction

The Quick Reference Guide lists the commands and queries with their corresponding arguments and returned formats. The arguments for each command list the minimum argument required. The part of the command or query listed in uppercase letters refers to the short form of that command or query. The long form is the combination of uppercase and lowercase letters.

Conventions

The following conventions are used in this guide:

- <> Angular brackets enclose words or characters that symbolize a program code parameter or an HP-IB command.
- ::= "is defined as." For example, <A> ::= indicates that <A> can be replaced by in any statement containing <A>.
- | "or." Indicates a choice of one element from a list. For example, <A> | indicates <A> or but not both.
- ... An ellipsis (trailing dots) indicate that the preceding element may be repeated one or more times.
- [] Square brackets indicate that the enclosed items are optional.
- { } When several items are enclosed by braces, one, and only one of these elements may be selected.

Suffix Multipliers

The suffix multipliers available for arguments are:

EX::= 1E18	M::= 1E-3
PE::= 1E15	U::= 1E-6
T::= 1E12	N::=1E-9
G::=1E9	P::=1E-12
MA::=1E6	F::= 1E-15
K::= 1E3	A::= 1E-18

For more information on specific commands or queries, refer to the *HP 54520C and 54540C Series Oscilloscopes Programmer's Reference*.

*CLS

Command *CLS

*DMC

Command *DMC <ascii_string>,<block_data>
Where: <ascii_string> ::= a quoted ascii string
<block_data> ::= definite block data in IEEE 488.2 # format

*EMC

Command *EMC {{OFF| 0} | {ON |1})
Query *EMC?
Returned Format {0| 1}<NL>

*ESE

Command *ESE <mask_argument>
Query *ESE?
Returned Format <mask_argument><NL>
Where: <mask_argument> ::= integer, 0 to 255

*ESR?

Query *ESR?
Returned Format <status><NL>
Where: <status> ::= integer, 0 to 255

*GMC?

Query *GMC? <ascii_string>
Returned Format <block_data><NL>
Where: <ascii_string> ::= a quoted string
<block_data> ::= definite block data in # format

Programmer's Quick Reference Guide

*IDN?

Query	*IDN?
Returned Format	HEWLETT-PACKARD,545XXC,YYYYYYYYYY,ZZ.ZZ,ZZ.ZZ,ZZ.ZZ,Z.ZZZ,<NL>
Where:	<XXC> ::= model number is 20C (HP 54520C), 22C (HP 54522C), 40C (HP 54540C), or 42C (HP 54542C) <YYYYYYYYYY> ::= the serial number of the instrument <ZZ.ZZ> ::= the software revision of the software modules (Boot ROM, Flash ROM version of Boot ROM, System, Keyboard ROM). 00.00 = not installed <Z.ZZZ> ::= the telecommunication mask option null = no option, 0.001 = option installed

*LMC

Query	*LMC?
Returned Format	<ascii_string><NL>
Where:	<ascii_string> ::= string list separated by commas

*LRN?

Query	*LRN?
Returned Format	:SYSTem:SETEup <setup><NL>
Where:	<setup> ::= #800002048<learn_string> <learn_string> ::= 2048 bytes in length

*OPC

Command	*OPC
Query	*OPC?
Returned Format	1<NL>

*OPT ?

Query	*OPT?
Returned Format	0<NL> or 000.1<NL>
Where:	0 = no option 0.001 = telecom mask option installed

*PMC

Command *PMC

*RCL

Command *RCL {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9}

*RST

Command *RST

*SAV

Command *SAV {1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9}

*SRE

Command *SRE <mask_argument>
Query *SRE?
Returned Format <mask><NL>
Where: <mask_argument> ::= integer, 0 to 255
 <mask> ::= sum of all bits that are set - integer, 0 through
 255

*STB?

Query *STB?
Returned Format <value><NL>
Where: <value> ::= integer, 0 through 255

*TRG?

Command *TRG

Programmer's Quick Reference Guide

*TST?

Query	*TST?
Returned Format	<result><NL>
Where:	<result> ::= 0 or non-zero value. 0 indicates the test passed. non-zero indicates the test failed

*WAI

Command *WAI

:ACQuire:COMplete

Command	:ACQuire:COMPLETE <complete_argument>
Query	:ACQuire:COMPLETE?
Returned Format	[:ACQuire:COMPLETE] <complete_argument><NL>
Where:	<complete_argument> ::= integer, 0 to 100 percent

:ACQuire:COUNt

Query	:ACQuire:COUNT <count_argument>
Returned Format	:ACQuire:COUNT?
Where:	[:ACQuire:COUNT] <count_argument><NL> <count_argument> ::= integer, 1 to 2048 (depending on the acquisition type)

:ACQuire:POINts

Command	:ACQuire:POINTs <points_argument>
Query	:ACQuire:POINTs?
Returned Format	[:ACQuire:POINTs] <points_argument><NL>
Where:	<points_argument> ::= integer, 500 in repetitive mode, 512, 1024, 2048, 4196, 8192, 16384, or 32768 in the real-time mode (sequential mode off), or 4 through 32768 in the real-time mode (sequential mode on)

:ACQuire:TYPE

Command	:ACQuire:TYPE {NORMAL AVERage ENVelope PDETect RAWData[,<length>][,<acquisitions>]][,{NORMAL AVERage ENVelope }]
Query	:ACQuire:TYPE?
Returned Format	[{:ACQuire:TYPE] {NORMAL AVERage ENVelope PDETect RAWData,<length>,<acquisitions><NL>}

Where:

<length> ::= integer, 4 to 32768
<acquisitions> ::= dependent on length of acquisitions and
buffer size

:AUToscale

Command	:AUToscale
Query	:AUToscale?
Returned Format	[{:AUToscale] {0 1}<NL>}

:BEEPer

Command	:BEEPer [{OFF 0} {ON 1}]
Query	:BEEPer?
Returned Format	[{:BEEPer] {0 1}<NL>}

:BLANK

Command	:BLANK <display>
Where:	<display> ::= {CHANnel<n> FUNCtion{1 2 3 4} WMEMory{1 2 3 4} PMEMory{1 2}} <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)

:BNC

Command	:BNC {PROBe TRIGger}
Query	:BNC?
Returned Format	[{:BNC] {PROBe TRIGger}<NL>}

Programmer's Quick Reference Guide

:CALibrate:DATA:ASCii?

Query :CALibrate:DATA:ASCii?
Returned Format [:CALibrate:DATA:ASCII] <data>,<data>,...<NL>
Where: <data> ::= calibration data

:CALibrate:SETup?

Query :CALibrate:SETup?
Returned Format [:CALibrate:TNULL]
Where: <null_value_n>,<null_value_n>,<null_value_n><NL>
<null_value_n> ::= exponential, channel 1 to channel<n> skew,
where n = 2 (HP 54520C/54522C) or 2 through 4
(HP 54540C/54542C) in format

:CALibrate:TNULL

Command :CALibrate:TNULL <null_value_n>
Query :CALibrate:TNULL?
Returned Format [:CALibrate:TNULL] <null_value_n><NL>
Where: <null_value_n> ::= exponential, channel 1 to channel<n> skew,
where n = 2 (HP 54520C/54522C) or 2 through 4
(HP 54540C/54542C)

:CHANnel<n>:COUpling

Command :CHANnel<n>:COUpling {AC | DC | DCFifty}
Query :CHANnel<n>:COUpling?
Returned Format [:CHANnel<n>:COUpling] {AC | DC | DCFifty}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:CHANnel<n>:DISPLAY

Command :CHANnel<n>:DISPLAY {{OFF | 0} | {ON | 1}}
Query :CHANnel<n>:DISPLAY?
Returned Format [:CHANnel<n>:DISPLAY {0 | 1}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:CHANnel<n>:ECL

Command :CHANnel<n>:ECL
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:CHANnel<n>:HFReject

Command :CHANnel<n>:HFReject {{OFF | 0} | {ON | 1}}
Query :CHANnel<n>:HFReject?
Returned Format [:CHANnel<n>:HFReject] {0 | 1}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:CHANnel<n>:LFReject

Command :CHANnel<n>:LFReject {{OFF | 0} | {ON | 1}}
Query :CHANnel<n>:LFReject?
Returned Format [:CHANnel<n>:LFReject] {0 | 1}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:CHANnel<n>:OFFSet

Command :CHANnel<n>:OFFSet <offset_argument>
Query :CHANnel<n>:OFFSet?
Returned Format [:CHANnel<n>:OFFSet] <offset_argument><NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)
<offset_argument> ::= exponential, offset value in volts

Programmer's Quick Reference Guide

:CHANnel<n>:PROBe

Command	:CHANnel<n>:PROBe <probe_argument>
Query	:CHANnel<n>:PROBe?
Returned Format	[:CHANnel<n>:PROBe] <probe_argument><NL>
Where:	<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C) <probe_argument> ::= exponential, 0.9 to 1000.0

:CHANnel<n>:RANGE

:CHANnel<n>:SETup

Query Returned Format	<pre>:CHANnel<n>:SETup? :CHAN<n>:COUP {AC DC DCF}; DISP {0 1}; HFR {0 1}; LFR {0 1}; OFFS <offset_argument>; PROB <probe_argument>; RANG<range_argument<NL> Where: <range_argument> ::= exponential, full-scale range value <offset_argument> ::= exponential, offset value in volts <probe_argument> ::= exponential, 0.9 to 1000.0 <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)</pre>
--------------------------	--

:CHANnel<n>;TTL

Command :CHANnel<n>:TTL
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
 (HP 54540C/54542C)

:DIGItize

Command
Where:

```
:DIGItize CHANnel<n>[,CHANnel<n>[,CHANnel<n>[,CHANnel<n>]]]
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
      (HP 54540C/54542C)
```

:DISK:CDIRectory

Command
Where:

```
:DISK:CDirectory <directory_name>
<directory_name> ::= 1 to 65 character quoted ASCII string
```

:DISK:DELetE

Command
Where:

```
:DISK:DELetE <file_name>
<file_name> ::= 1 to 8 character quoted ASCII string, if DOS,
can have a 0 to 3 character extension
```

:DISK:DIRectory?

Query
Returned Format
Where:

```
:DISK:DIRectory?
[:DISK:DIRectory] <number_of_files><cr><lf><directory>
<number_of_files> ::= integer, number of files (that follow)
in the root directory
<directory> ::= <filename>,<ext>,<date>,<time>,<size>,
   <description><cr><lf>...
<ext> ::= {SETup | WAVEform | TEXT | PIXel}
<date> ::= DDMMYY
<time> ::= HH:MM:SS
<size> ::= an integer
<description> ::= LIF format: Model + C1 + HP545XX + Source,
DOS format: Model = DOS file (no description)
```

:DISK:FORMAT

Command
Where:

```
:DISK:FORMAT <format_type>
<format_type> ::= {DOS | LIF}
```

Programmer's Quick Reference Guide

:DISK:LOAD

Command :DISK:LOAD <file_name>,<destination> [,<format>]
Where: <filename> ::= quoted ascii string DOS compatible filename.
1 to 8 character ASCII string, if DOS, may have a 0 to 3
character extension
Either .wav or .txt may be used as a suffix after the
filename. If no file suffix is specified, the default is
.wav.
<destination> ::= {WMemory {1 | 2 | 3 | 4} |
SETup{0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9} |
PMEMemory{ 1 | 2}}
<format>::= {TEXT | INTernal}

:DISK:MDIRectory

Command :DISK:MDirectory <directory_name>
Where: <directory_name> ::= 1 to 65 character quoted ASCII string

:DISK:PWD?

Query :DISK:PWD?
Returned Format: [:DISK:PWD] <present_working_directory>

:DISK:SIMage

Command :DISK:SIMage <file_name> [|,<format>] [|,<compression>|
|,<rendering>|]
Where: <filename>::= 1 to 8 character quoted ASCII string, if DOS,
can have a 0 to 3 character extension
<format>::={TIFF | PCX | EPS}
<compression>::={ON | OFF}
<rendering>::={BW | COLOR [GReen]}

:DISK:STORe

Command
Where:

```
:DISK:STORe <source>,<file_name>[,<format>]
<source> ::= {CHANnel<n> | WMMemory{1 | 2 | 3 | 4} | ...
SETupN {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9} | ...
PMEMory {1 | 2}
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)
<filename> ::= a descriptive name of the file up to 8
characters long
<format> ::= {INTernal | TEXT [, {<XYPairs> | <YValues> |
<VERBose>}]}
```

:DISPLAY:COLumn

Command
Query
Returned Format
Where:

```
:DISPLAY:COLumn <column_number>
:DISPLAY:COLumn?
[:DISPLAY:COLumn] <column_number><NL>
<column_number> ::= integer, 0 through 78
```

:DISPLAY:CONNect

Command
Query
Returned Format
Where:

```
:DISPLAY:CONNect {{OFF | 0} | {ON | 1}}
:DISPLAY:CONNect?
[:DISPLAY:CONNect] {0 | 1}<NL>
```

:DISPLAY:DATA

Command
Query
Returned Format
Where:

```
:DISPLAY:DATA <binary_block>
:DISPLAY:DATA?
[:DISPLAY:DATA] #800016576<16576 bytes of binary data><NL>
<binary_block> ::= definite block data in # format
```

:DISPLAY:FORMAT

Command
Query
Returned Format
Where:

```
:DISPLAY:FORMAT {1 | 2 | 4}
:DISPLAY:FORMAT?
[:DISPLAY:FORMAT] {1 | 2 | 4}<NL>
```

Programmer's Quick Reference Guide

:DISPlay:GRATicule

Command :DISPLAY:GRATICULE {AXES | GRID | FRAMe| OFF}
Query :DISPLAY:GRATICULE?
Returned Format [:DISPLAY:GRATICULE] {AXES | GRID | FRAMe | OFF}<NL>

:DISPlay:INVerse

Command :DISPLAY:INVERSE {{OFF | 0} | {ON| 1}}
Query :DISPLAY:INVERSE?
Returned Format [:DISPLAY:INVERSE] {0| 1}<NL>

:DISPlay:LINE

Command :DISPLAY:LINE <ascii_string>
Where: <ascii_string> ::= any series of ascii characters enclosed in quotes

:DISPlay:MASK

Command :DISPLAY:MASK <mask_argument>
Query :DISPLAY:MASK?
Returned Format [:DISPLAY:MASK] <mask_argument><NL>
Where: <mask_argument> ::= integer, 0 through 255

:DISPlay:PERSistence

Command :DISPLAY:PERStistence {SINGle | INFinite | 0 | {0.5 to 10} | 11}
Query :DISPLAY:PERStistence?
Returned Format [:DISPLAY:PERStistence] <value><NL>
Where: <value> ::= exponential, {0 (minimum) | {0.5 to 10} | 11
 (infinite)} in the repetitive mode, {SINGLE | INFINITE} in
 real-time mode

:DISPLAY:ROW

Command :DISPLAY:ROW <row_number>
Query :DISPLAY:ROW?
Returned Format [:DISPLAY:ROW] <row_number><NL>
Where: <row_number> ::= integer, 0 through 24

:DISPLAY:SCReen

Command :DISPLAY:SCReen {{OFF | 0} | {ON | 1}}
Query :DISPLAY:SCReen?
Returned Format [:DISPLAY:SCReen] {0 | 1}<NL>

:DISPLAY:SETUp?

Query :DISPLAY:SETUp?
Returned Format :DISP:COL <column_number>;
CONN {0 | 1};
FORM {1 | 2 | 4};
GRAT {AXES | FRAM | GRID | OFF};
INV {0 | 1};
MASK <mask_argument>;
PERS <pers_argument>;
ROW <row_number>;
SCR {0 | 1};
SOUR PMEM {0 | 1 | 2};
MARK {0 | 1}<NL>
Where: <column_number> ::= integer, 0 through 78
<mask_argument> ::= integer, 0 to 255
<pers_argument> ::= exponential, {0 | .5 to 10 | 11} in the
repetitive mode, {SINGLE | INFINITE} in the real-time mode
<row_number> ::= integer, 0 to 24

:DISPLAY:SOURce

Command :DISPLAY:SOURce PMEMORY{0 | 1 | 2 }
Query :DISPLAY:SOURce?
Returned Format [:DISPLAY:SOURce] PMEMORY{0 | 1 | 2 }<NL>

Programmer's Quick Reference Guide

:DISPlay:STRing

Command :DISPLAY:STRING <string_argument>
Where: <string_argument> ::= text string up to 90 characters

:DISPlay:TEXT

Command :DISPLAY:TEXT BLANK

:DISPlay:{MARKer|TMARKer|VMARKer}

Command :DISPLAY:{MARKer|TMARKer|VMARKer} {{OFF | 0} | {ON | 1}}
Query :DISPLAY:MARKer|TMARKer|VMARKer?
Returned Format [:DISPLAY:MARKer|TMARKer|VMARKer] {0 | 1}<NL>

:ERASe

Command :ERASE {PMEMory0<pmemory_num>}
Where: <pmemory_num> ::= integer, 1 or 2 @MODULE RULE =

:EXTernal:COUPling

Command :EXTERNAL:COUPLING {AC | DC | DCFifty}
Query :EXTERNAL:COUPLING?
Returned Format [:EXTERNAL:COUPLING] {AC | DC | DCFifty}<NL>

:EXTernal:HFReject

Command :EXTERNAL:HFREJECT {{OFF | 0} | {ON | 1}}
Query :EXTERNAL:HFReject?
Returned Format [:EXTERNAL:HFReject] {0 | 1}<NL>

:EXTernal:LFReject

Command	:EXTernal:LFReject {{OFF 0} {ON 1}}
Query	:EXTernal:LFReject?
Returned Format	[{:EXTernalLFReject] {0 1}<NL>

:EXTernal:PROBe

Command	:EXTernal:PROBe <probe_argument>
Query	:EXTernal:PROBe?
Returned Format	[{:EXTernal:PROBe] <probe_argument><NL> <probe_argument> ::= exponential, 0.9 to 1000.0

:EXTernal:RANGE

Command	:EXTernal:RANGE <range_argument>
Query	:EXTernal:RANGE?
Returned Format	[{:EXTernal:RANGE] <range_argument><NL> <range_argument> ::= exponential, full-scale range value

:EXTernal:SETUp

Query	:EXTernal:SETUp?
Returned Format	:EXT:COUP {AC DC DCF}; HFR {0 1}; LFR {0 1}; PROB <probe_argument>; RANG<range_argument><NL> <range_argument> ::= exponential, full-scale range value <probe_argument> ::= exponential, 0.9 to 1000.0
Where:	

:FUNCTION{1|2|3|4}:ADD

Command	:FUNCTION{1 2 3 4}:ADD <operand>,<operand>
Where:	<operand> ::= {CHANnel<n> WMEMory{1 2 3 4}} <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)

Programmer's Quick Reference Guide

:FUNCTION{1|2|3|4}:DIFF

Command :FUNCTION{1 | 2 | 3 | 4}:DIFF <operand>
Where: <operand> ::= {CHANnel<n> | WMEMORY{1 | 2 | 3 | 4})
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:DISPLay

Command :FUNCTION{1 | 2 | 3 | 4}:DISPLAY {{OFF | 0} | {ON | 1}}
Query :FUNCTION{1 | 2 | 3 | 4}:DISPLAY?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}[:DISPLAY] {0 | 1}<NL>

:FUNCTION{1|2|3|4}:FFT

Command :FUNCTION{1 | 2 | 3 | 4}:FFT <operand>
Where: <operand> ::= {CHANnel<n> | WMEMORY{1 | 2 | 3 | 4})
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:FREQuency

Command :FUNCTION{1 | 2 | 3 | 4}:FREQUENCY <frequency_argument>
Query :FUNCTION{1 | 2 | 3 | 4}:FREQUENCY?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:FREQUENCY] <frequency_argument><NL>
Where: <frequency_argument> ::= exponential, center frequency from
0 Hz to 1.5X of frequency span

:FUNCTION{1|2|3|4}:INTegrate

Command :FUNCTION{1 | 2 | 3 | 4}:INTegrate <operand>
Where: <operand> ::= {CHANnel<n> | WMEMORY{1 | 2 | 3 | 4})
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:INVert

Command Where: :FUNCTION{1 | 2 | 3 | 4}:INVert <operand>
<operand> ::= {CHANnel<n> | WMemory{1 | 2 | 3 | 4}}
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
 (HP 54540C/54542C)

:FUNCtion{1|2|3|4}:LEVel

Command	:FUNCTION{1 2 3 4}:LEVEL <level_argument>
Query	:FUNCTION{1 2 3 4}:LEVEL?
Returned Format	[:FUNCTION{1 2 3 4}:LEVEL] <level_argument><NL>
Where:	<level_argument> ::= exponential, level value 0 to + or - 600 dbm

:FUNCTION{1|2|3|4}:MAGNify

Command :FUNCTION{1 | 2 | 3 | 4}:MAGNify {{OFF | 0} | {ON | 1}}
Query :FUNCTION{1 | 2 | 3 | 4}:MAGNify?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:MAGNify] {0 | 1}<NL>

:FUNCTION{1|2|3|4}:MODE?

Query	:FUNCTION{1 2 3 4}:MODE?
Returned Format	[:FUNCTION{1 2 3 4}:MODE] <operation>, <operand> [, <operand>] <operation> ::= {ADD SUBTract MULTIPLY VERSus ONLY INVert INTegrate DIFF FFT} <operand> ::= {CHANnel<n> WMEMory{1 2 3 4}} <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)
Where:	

:FUNCTION{1|2|3|4}:MULTIPLY

Programmer's Quick Reference Guide

:FUNCTION{1|2|3|4}:OFFSet

Command :FUNCTION{1 | 2 | 3 | 4}:OFFSet <offset_argument>
Query :FUNCTION{1 | 2 | 3 | 4}:OFFSet?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:OFFSet] <offset_argument><NL>
Where: <offset_argument> ::= exponential, offset value of 0 to
±voltage full scale, or 0 to ±200 dbm for FFT

:FUNCTION{1|2|3|4}:ONLY

Command :FUNCTION{1 | 2 | 3 | 4}:ONLY <operand>
Where: <operand> ::= {CHANnel<n> | WMEMORY{1 | 2 | 3 | 4})
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:PEAK

Command :FUNCTION{1 | 2 | 3 | 4}:PEAK <peak1_number>, <peak2_number>
Query :FUNCTION{1 | 2 | 3 | 4}:PEAK?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:PEAK]
Where: <peak1_number>, <peak2_number><NL>
<peak1_number> ::= integer, 1 through 99
<peak2_number> ::= integer, 1 through 99

:FUNCTION{1|2|3|4}:POINTs

Command :FUNCTION{1 | 2 | 3 | 4}:POINTs <points_argument>
Query :FUNCTION{1 | 2 | 3 | 4}:POINTs?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:POINTs] <points_argument><NL>
Where: <points_argument> ::= integer, 512, 1024, 2048, 4096, 8192,
16384, or 32768

:FUNCTION{1|2|3|4}:RANGE

Command :FUNCTION{1 | 2 | 3 | 4}:RANGE <range_argument>
Query :FUNCTION{1 | 2 | 3 | 4}:RANGE?
Returned Format [:FUNCTION{1 | 2 | 3 | 4}:RANGE] <range_argument><NL>
Where: <range_argument> ::= exponential full scale vertical range in
volts, dB, or dBm

:FUNCTION{1|2|3|4}:SETUP?

Query	<code>:FUNCTION{1 2 3 4}:SETUP?</code>
Returned Format	<code>:FUNCTION{1 2 3 4}:DISP {0 1};</code> <code>{ADD SUBT MULT VERS ONLY INV INT DIFF </code> <code>FFT} [{CHAN<n> WMEM {1 2 3 4} [, {CHAN<n>} </code> <code>WMEM {1 2 3 4}]};</code> <code>OFF <offset_argument>;</code> <code>RANG <range_argument>;</code> <code>FREQ <frequency_argument>; (FFT only)</code> <code>LEV <level_argument>; (FFT only)</code> <code>MAGN {0 1}; (FFT only)</code> <code>PEAK <peak1_number>,peak2_number>; (FFT only)</code> <code>POIN <points_argument>; (FFT only)</code> <code>SPAN <span_argument>; (FFT only)</code> <code>WIND {RECT HANN FLAT} (FFT only)<NL></code>
Where:	<code><n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4</code> <code>(HP 54540C/54542C)</code> <code><offset_argument> ::= exponential offset value of 0 to ± 200</code> <code>dBm for FFT function</code> <code><range_argument> ::= exponential full scale vertical range in</code> <code>volts, dB, or dBm</code> <code><frequency_argument> ::= exponential center frequency from</code> <code>0 Hz to 1.5X of frequency span</code> <code><level_argument> ::= exponential level value 0 to ± 600 dBm</code> <code><peak1_number> ::= integer, 1 through 99</code> <code><peak2_number> ::= integer, 1 through 99</code> <code><points_argument> ::= integer, 512, 1024, 2048, 4096, 8192,</code> <code>16384, or 32768</code> <code><span_argument> ::= exponential number in hertz</code>

:FUNCTION{1|2|3|4}:SPAN

Command	<code>:FUNCTION{1 2 3 4}:SPAN <span_argument></code>
Query	<code>:FUNCTION{1 2 3 4}:SPAN?</code>
Returned Format	<code>[:FUNCTION{1 2 3 4}:SPAN] <span_argument><NL></code>
Where:	<code><span_argument> ::= exponential number in hertz</code>

Programmer's Quick Reference Guide

:FUNCTION{1|2|3|4}:SUBTract

Command Where: :FUNCTION{1 | 2|3|4}:SUBTract <operand1>,<operand2>
<operand1> ::= {CHANNEL<n> | WMEMORY{1 | 2 | 3 | 4}}
<operand2> ::= {CHANNEL<n> | WMEMORY{1 | 2 | 3 | 4}}
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:VERSus

Command Where: :FUNCTION{1 | 2 | 3 | 4}:VERSus <Y_operand>,<X_operand>
<Y_operand1> ::= {CHANNEL<n> | WMEMORY{1 | 2 | 3 | 4}}
<X_operand2> ::= {CHANNEL<n> | WMEMORY{1 | 2 | 3 | 4}}
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
(HP 54540C/54542C)

:FUNCTION{1|2|3|4}:WINDOW

Command :FUNCTION{1 | 2 | 3 | 4}:WINDOW {RECTangular | HANNing |
FLATtop}
Query :FUNCTION:WINDOW?
Returned Format [:FUNCTION{1|2|3|4}:WINDOW] {RECTangular | HANNing |
FLATtop}<NL>

:HARDcopy:LENGTH

Command :HARDcopy:LENGTH {11 | 11.6 | LETTER | A4}
Query :HARDcopy:LENGTH?
Returned Format [:HARDcopy:LENGTH] {11 | 11.6 | LETTER | A4}<NL>

:HARDcopy:MODE

Command	:HARDcopy:MODE {THINKJET DJ5XBW75DPI DJ5XBW100DPI DJ5XBW150DPI DJ5XBW300DPI DJET75DPI DJET100DPI DJET150DPI DJET300DPI LASERJET_II LASERJET_IIP PJETXL300 PJETXL PAINTJET COLORPRO HP7475A HP7470A HP7550A DJET310C DJET320C DJET500C DJET540C DJET560C DJET600C DJET660C DJET850C DJET855C P1200C QUIETJETALT EPSON5000}
Query Returned Format	:HARDcopy:MODE? [:HARDcopy:MODE] {THINKJET DJ5XBW75DPI DJ5XBW100DPI DJ5XBW150DPI DJ5XBW300DPI DJET75DPI DJET100DPI DJET150DPI DJET300DPI LASERJET_II LASERJET_IIP PJETXL300 PJETXL PAINTJET COLORPRO HP7475A HP7470A HP7550A DJET310C DJET320C DJET500C DJET540C DJET560C DJET600C DJET660C DJET850C DJET855C P1200C QUIETJETALT EPSON5000}<NL>

:HARDcopy:PAGE

Command	:HARDcopy:PAGE {MANual AUTomatic}
Query Returned Format	:HARDcopy:PAGE? [:HARDcopy:PAGE] {MANual AUTomatic}<NL>

:HARDcopy:PLOT:AREA

Command	:HARDcopy:PLOT:AREA {ALL DISPlay FACTors GRATicule LABeled}
Query Returned Format	:HARDcopy:PLOT:AREA? [:HARDcopy:PLOT:AREA] {ALL DISPlay FACTors GRATicule LABeled}<NL>

:HARDcopy:PLOT:INITialize

Command	:HARDcopy:PLOT:INITialize {{OFF 0} {ON 1}}
Query Returned Format	:HARDcopy:PLOT:INITialize? [:HARDcopy:PLOT:INITialize] {0 1}<NL>

:HARDcopy:PLOT:{PEN|COLOr}

Command	:HARDcopy:PLOT:{PEN COLOr} <item>,<pen_number>
Query	:HARDcopy:PLOT:{PEN COLOr}? <item>
Returned Format	[:HARDcopy:PLOT:{PEN COLOr}] <pen_number><NL>
Where:	<item> ::= {CHANnel<n> WMEMemory{1 2 3 4} FUNCTION{1 2 3 4} PMEMory{1 2} Y{1 2}Marker X{1 2}Marker GRATicule TRIGger TIMEbase MEASure TITLes} <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C) <pen_number> ::= integer, 0 through 8

:LER?

Query	:LER?
Returned Format	[:LER] {0 1}<NL>

:LTER?

Query	:LTER?
Returned Format	[:LTER] {0 1}<NL>

:MARKer:DISPlay

Command	:MARKer:DISPLAY {{OFF 0} {ON 1}}
Query	:MARKer:DISPLAY?
Returned Format	[:MARKer:DISPLAY] {0 1}<NL>

:MARKer:MODE

Command	:MARKer:MODE {MANual WAVEform}
Query	:MARKer:MODE?
Returned Format	[:MARKer:MODE] {MANual WAVEform}<NL>

:MARKer:SETup?

Query :MARKer:SETup?
Returned Format

```

:MARK:MODE {MAN| WAV};DISP {0 | 1};
    XDEL <xdelta>;
    X1P <xposition_argument>;
    X2P <xposition_argument>;
    X1Y1 {CHAN<n> | FUNC{1 | 2 | 3 | 4} | WMEM{1 | 2 | 3 | 4}};
    X2Y2 {CHAN<n> | FUNC{1 | 2 | 3 | 4} | WMEM{1 | 2 | 3 | 4}};
    Y1P <yposition_argument>;          (MAN mode only)
    Y2P <yposition_argument>;          (MAN mode only)
    YDEL <ydelta>;                  (MAN mode only)
    Y1P <yposition_argument>;          (MAN mode only)
    Y2P <yposition_argument><NL>   (MAN mode only)

```

Where:

```

<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4
      (HP 54540C/54542C)
<xdelta> ::= exponential, difference in seconds between x1 and
      x2 markers
<xposition_argument> ::= exponential, xmarker position in
      seconds or hertz
<ydelta> ::= exponential, difference between y1 and y2 markers
<yposition_argument> ::= exponential, ymarker position in volts
      or power

```

:MARKer:X1Position

Command :MARKer:X1Position <xposition_argument>
Query :MARKer:X1Position?
Returned Format [:MARKer:X1Position] <xposition_argument><NL>
Where: <xposition_argument> ::= exponential, xmarker time in seconds,
 or frequency in hertz

:MARKer:X2Position

Command :MARKer:X2Position <xposition_argument>
Query :MARKer:X2Position?
Returned Format [:MARKer:X2Position] <xposition_argument><NL>
Where: <xposition_argument> ::= exponential, xmarker time in
 seconds,
 or frequency in hertz

:MARKer:X1Y1source

Command :MARKer:X1Y1source {CHANnel<n> | {FUNCTION{1 | 2 | 3 | 4} | WMEMemory{1 | 2 | 3 | 4}}}
Query :MARKer:X1Y1source?
Returned Format [:MARKer:X1Y1source] {CHANnel<n>| {FUNCTION{1 | 2 | 3 | 4} | WMEMemory{1 | 2 | 3 | 4}}}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)

:MARKer:X2Y2source

Command :MARKer:X2Y2source {CHANnel<n> | {FUNCTION{1 | 2 | 3 | 4} | WMEMemory{1 | 2 | 3 | 4}}}
Query :MARKer:X2Y2source?
Returned Format [:MARKer:X2Y2source] {CHANnel<n>| {FUNCTION{1 | 2 | 3 | 4} | WMEMemory{1 | 2 | 3 | 4}}}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)

:MARKer:XDELta?

Query :MARKer:XDELta?
Returned Format [:MARKer:XDELta] <xdelta><NL>
Where: <xdelta> ::= exponential, difference between x1 and x2 markers

:MARKer:Y1Position (Command ignored in waveform mode)

Command :MARKer:Y1Position <yposition_argument>
Query :MARKer:Y1Position?
Returned Format [:MARKer:Y1Position] <yposition_argument><NL>
Where: <yposition_argument> ::= exponential, ymarker level in volts, or power in dBm

:MARKer:Y2Position (Command ignored in waveform mode)

Command :MARKer:Y2Position <yposition_argument>
Query :MARKer:Y2Position?
Returned Format [:MARKer:Y2Position] <yposition_argument><NL>
Where: <yposition_argument> ::= exponential, ymarker level in volts,
 or power in dBm

:MARKer:YDELta?

Query :MARKer:YDELta?
Returned Format [:MARKer:YDELta] <ydelta><NL>
Where: <ydelta> ::= exponential, difference between y1 and y2 markers

:MEASure:ALL?

Query :MEASURE:ALL?
Returned Format [:MEASURE] [:DElay] <result>; [:DUTycycle] <result>;
 [:FALLtime] <result>; [:FREQuency] <result>; [:NWIDth]
 <result>; [:OVERshoot] <result>; [:PERiod] <result>;
 [:PREShoot] <result>; [:PWIDth] <result>; [:RISetime]
 <result>; [:VACRms] <result>; [:VAMplitude] <result>;
 [:VAVerage] <result>; [:VBASe] <result>; [:VDCRms] <result>;
 [:VMAX] <result>; [:VMIN] <result>; [:VPP] <result>; [:VTOP]
 <result>; <NL>
Where: <result> ::= exponential, individual measurement results

:MEASure:COMPARE

Command :MEASURE:COMPARE <measurement>,<upper_limit>,<lower_limit>
Query :MEASURE:COMPARE? <measurement>
Returned Format [:MEASURE:COMPARE]
Where: <measurement>,<upper_limit>,<lower_limit><NL>
 <measurement> ::= {DElay | DUTycycle | FALLtime | FREQuency |
 NWIDth | OVERshoot | PERiod | PREShoot | PWIDth | RISetime |
 VACRms | VAMplitude | VAVerage | VBASe | VDCRms | VMAX |
 VMIN | VPP | VTOP}
 <upper_limit> ::= exponential, high limit value
 <lower_limit> ::= exponential, low limit value

Programmer's Quick Reference Guide

:MEASure:CURSor?

Query :MEASure:CURSor? {DELTa | STARt | STOP}
Returned Format [:MEASure:CURSor] <time>,<voltage><NL>
Where: <time> ::= exponential, delta time, y1marker time, or y2marker
time
<voltage> ::= exponential, delta voltage, x1marker voltage, or
x2marker voltage

:MEASure:DEFine

Command :MEASure:DEFine <define_argument>
Query :MEASure:DEFine? {DELay | PWIDth | NWIDth}
Returned Format [:MEASure:DEFine] <define_argument><NL>
Where: <define_argument> ::= {DELay,<polarity>,<edge_number>,<level>,
<polarity>,<edge_number>,<level> | PWIDth,<level> |
NWIDth,<level>}
<polarity> ::= {POSitive | NEGative}
<edge_number> ::= integer, 1 to 4000 specifying a displayed
edge
<level> ::= {MIDDLE | UPPer | LOWER}

:MEASure:DELay

Command :MEASure:DELay
Query :MEASure:DELay?
Returned Format [:MEASure:DELay] <value><NL>
Where: <value> ::= exponential, time value in seconds

:MEASure:DESTination

Command	<code>:MEASure:DESTination <source_argument>,<destination_argument></code>
Query	<code>:MEASure:DESTination? {CHANnel<n> FUNCTion{1 2 3 4} SCReen?}</code>
Returned Format	<code>[:MEASure:DESTination] {{CHANnel<n> {FUNCTION{1 2 3 4} SCReen}}] {WMEMory{1 2 3 4} PMEMory{1 2} MULTiple OFF}<NL></code>
Where:	<code><source_argument> ::= {{SCReen,{OFF PMEMory{1 2}}}} {{CHANnel<n> FUNCTion{1 2 3 4}}}</code> <code><destination_argument> ::= {WMEMory{1 2 3 4} MULTiple OFF}</code> <code><n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)</code>

:MEASure:DUTycycle

Command	<code>:MEASure:DUTycycle</code>
Query	<code>:MEASure:DUTycycle?</code>
Returned Format	<code>[:MEASure:DUTycycle] <value><NL></code>
Where:	<code><value> ::= exponential, ratio of positive pulse width to period</code>

:MEASure:ESTArt

Command	<code>:MEASure:ESTArt <slope_and_occurrence></code>
Query	<code>:MEASure:ESTArt?</code>
Returned Format	<code>[:MEASure:ESTArt] <slope_and_occurrence><NL></code>
Where:	<code><slope_and_occurrence> ::= integer, -4000 to 4000 (excluding 0)</code>

:MEASure:ESTOp

Command	<code>:MEASure:ESTOp <slope_and_occurrence></code>
Query	<code>:MEASure:ESTOp?</code>
Returned Format	<code>[:MEASure:ESTOp] <slope_and_occurrence><NL></code>
Where:	<code><slope_and_occurrence> ::= integer, -4000 to 4000 (excluding 0)</code>

:MEASure:EANalysis

Command :MEASure:EANalysis {{OFF | 0} | {ON | 1}}
Query :MEASure:EANalysis?
Returned Format [:MEASure:EANalysis] {0 | 1}<NL>

:MEASure:FALLtime

Command :MEASure:FALLtime
Query :MEASure:FALLtime?
Returned Format [:MEASure:FALLtime] <value><NL>
Where: <value> ::= exponential, time value in seconds between lower threshold and upper threshold voltage points

:MEASure:FREQuency

Command :MEASure:FREQuency
Query :MEASure:FREQuency?
Returned Format [:MEASure:FREQuency] <value><NL>
Where: <value> ::= exponential, frequency in hertz

:MEASure:LIMittest

Command :MEASure:LIMittest {MEASure | OFF}

:MEASure:LOWER

Command :MEASure:LOWER [<source>,]<lower_threshold>
Query :MEASure:LOWER? [<source>]
Returned Format [:MEASure:LOWER] <source>,<lower_threshold><NL>
Where: <source> ::= {CHANnel<n> | FUNCtion{1 | 2 | 3 | 4} | WMEMemory{1 | 2 | 3 | 4}}
<lower_threshold> ::= integer, user defined lower threshold in percent or volts (selected by :MEASure:UNITs)
<n> ::= integer 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

:MEASure:MODE

Command :MEASure:MODE {STANDARD | USER}
Query :MEASure:MODE?
Returned Format [:MEASure:MODE] {STANDARD | USER}<NL>

:MEASure:MWINDow

Command :MEASure:MWINDow {MARKers | SCReen}
Query :MEASure:MWINDow?
Returned Format [:MEASure:MWINDows] {MARKers | SCReen}<NL>

:MEASure:NWIDth

Command :MEASure:NWIDth
Query :MEASure:NWIDth?
Returned Format [:MEASure:NWIDth] <value><NL>
Where: <value> ::= exponential, negative pulse width in seconds

:MEASure:OVERshoot

Command :MEASure:OVERshoot
Query :MEASure:OVERshoot?
Returned Format [:MEASure:OVERshoot] <value><NL>
Where: <value> ::= exponential, ratio of overshoot to Vamplitude

:MEASure:PERiod

Command :MEASure:PERiod
Query :MEASure:PERiod?
Returned Format [:MEASure:PERiod] <value><NL>
Where: <value> ::= exponential, waveform period in seconds

:MEASure:POSTfailure

Command :MEASure:POSTfailure {CONTinue | STOP}
Query :MEASure:POSTfailure?
Returned Format [:MEASure:POSTfailure] {CONTINUE | STOP}<NL>

:MEASure:PREShoot

Command :MEASure:PREShoot
Query :MEASure:PREShoot?
Returned Format [:MEASure:PREShoot] <value><NL>
Where: <value> ::= exponential, ratio of preshoot to Vamplitude

:MEASure:PWIDth

Command :MEASure:PWIDth
Query :MEASure:PWIDth?
Returned Format [:MEASure:PWIDth] <value><NL>
Where: <value> ::= exponential, width of positive pulse in sseconds

:MEASure:RESults?

Query :MEASure:RESults?
Returned Format [:MEASure:RESults] <number_of_meas>[;<measurement>]...<NL>
Where: <number_of_meas> ::= integer, number of measurements displayed
on the screen, 0 through 23
<measurement> ::= {DELay <result> | DUTycycle <result> |
FALLtime <result> | FREQuency <result> | NWIDth <result> |
OVERshoot <result> | PERiod <result> | PREShoot <result> |
PWIDth <result> | RISetime <result> | TMAX <result> | TMIN
<result> | TVOLT <result> | VACRms <result> VAMplitude
<result> | VAVerage <result> | VBASe <result> | VDCRms
<result> | VMAX <result> | VMIN <result> | VPP <result> |
VTIMe <result> | VTOP <result>}
<result> ::= exponential, individual measurement results

:MEASure:RISetime

Command :MEASure:RISetime
Query :MEASure:RISetime?
Returned Format [:MEASure:RISetime] <value><NL>
Where: <value> ::= exponential, rise time in seconds

:MEASure:SCRatch

Command	<code>:MEASure:SCRatch</code>
----------------	-------------------------------

:MEASure:SOURce

Command	<code>:MEASure:SOURce <source>[,<source>]</code>
Query	<code>:MEASure:SOURce?</code>
Returned Format	<code>[:MEASure:SOURce] <source>[,<source>]<NL></code>
Where:	<code><source> ::= {CHANnel<n> FUNCTION{1 2 3 4} WMEMemory{1 2 3 4}}</code>
	<code><n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)</code>

:MEASure:STATistics

Command	<code>:MEASure:STATistics {{OFF 0) (ON 1)}</code>
Query	<code>:MEASure:STATistics?</code>
Returned Format	<code>[:MEASure:STATistics] {0 1}<NL></code>

MEASure:STATistics:MODE

Command	<code>:MEASure:STATistics:MODE {NORMAl SDEViation}</code>
Query	<code>:MEASure:STATistics:MODE?</code>
Returned Format	<code>[:MEASure:STATistics:MODE] {NORMAl SDEViation}<NL></code>

:MEASure:TDELta

Query	<code>:MEASure:TDELta?</code>
Returned Format	<code>[:MEASure:TDELta] <value><NL></code>
Where:	<code><value> ::= exponential, difference between x2 and x1 markers</code>

:MEASure:TMAX?

Query	<code>:MEASure:TMAX?</code>
Returned Format	<code>[:MEASure:TMAX] <time><NL></code>
Where:	<code><time> ::= exponential, time at maximum voltage</code>

Programmer's Quick Reference Guide

:MEASure:TMIN?

Query :MEASure:TMIN?
Returned Format [:MEASure:TMIN] <time><NL>
Where: <time> ::= exponential, time at minimum voltage

:MEASure:TSTArt

Command :MEASure:TSTArt <tstart_argument>
Query :MEASure:TSTArt?
Returned Format [:MEASure:TSTArt] <tstart_argument><NL>
Where: <tstart_argument> ::= exponential, time at x1marker in seconds

:MEASure:TSTOP

Command :MEASure:TSTOP <tstop_argument>
Query :MEASure:TSTOP?
Returned Format [:MEASure:TSTOP] <tstop_argument><NL>
Where: <tstop_argument> ::= exponential, time at x2marker in seconds

:MEASure:TVOLT?

Query :MEASure:TVOLt? <tvolt_argument>,<slope_and_occurrence>
Returned Format [:MEASure:TVOLt] <time><NL>
Where: <tvolt_argument> ::= real number representing positive or
negative voltage level that the waveform must cross
<slope_and_occurrence> ::= slope is the direction of the
waveform when <voltage> is crossed - rising (space character
or +) or falling (-)
occurrence is the number of crossings to be reported (if one
- the first crossing is reported, if two - the second
crossing is reported
<time> ::= exponential, time in seconds of specified voltage
crossing

:MEASure:UNITS

Command :MEASURE:UNITS {PERCent | VOLTs}
Query :MEASURE:UNITS?
Returned Format [:MEASURE:UNITS] {PERCent | VOLTs}<NL>

:MEASure:UPPer

Command :MEASURE:UPPer [<source,>]<upper_threshold>
Query :MEASURE:UPPer? [<source>]
Returned Format [:MEASURE:UPPer] <source>,<upper_threshold><NL>
Where: <source> ::= {CHANnel<n> | FUNCTION{1 | 2 | 3 | 4} |
WMEMory{1 | 2 | 3 | 4}}
<upper_threshold> ::= integer, user defined upper threshold in
percent or volts (selected by :MEASURE:UNITS)
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:MEASure:VACRms

Command :MEASURE:VACRms
Query :MEASURE:VACRms?
Returned Format [:MEASURE:VACRms] <value><NL>
Where: <value> ::= exponential, calculated ac rms voltage

:MEASure:VAMPLitude

Command :MEASURE:VAMPLitude
Query :MEASURE:VAMPLitude?
Returned Format [:MEASURE:VAMPLitude] <value><NL>
Where: <value> ::= exponential, difference between top and base
voltages

:MEASure:VAverage

Command :MEASURE:VAverage
Query :MEASURE:VAverage?
Returned Format [:MEASURE:VAverage] <value><NL>
Where: <value> ::= exponential, calculated average voltage

Programmer's Quick Reference Guide

:MEASure:VBASe

Command :MEASure:VBASe
Query :MEASure:VBASe?
Returned Format [:MEASure:VBASe] <value><NL>
Where: <value> ::= exponential, voltage at base of selected waveform

:MEASure:VDCRms

Command :MEASure:VDCRms
Query :MEASure:VDCRms?
Returned Format [:MEASure:VDCRms] <value><NL>
Where: <value> ::= exponential, calculated dc rms voltage

:MEASure:VDELta?

Query :MEASure:VDELta?
Returned Format [:MEASure:VDELta] <value><NL>
Where: <value> ::= exponential, delta V value in volts

:MEASure:VFIFTy

Command :MEASure:VFIFTy

:MEASure:VMAX

Command :MEASure:VMAX
Query :MEASure:VMAX?
Returned Format [:MEASure:VMAX] <value><NL>
Where: <value> ::= exponential, maximum voltage of selected waveform

:MEASure:VMIN

Command :MEASure:VMIN
Query :MEASure:VMIN?
Returned Format [:MEASure:VMIN] <value><NL>
Where: <value> ::= exponential, minimum voltage value of the selected waveform

:MEASure:VPP

Command :MEASURE:VPP
Query :MEASURE:VPP?
Returned Format [:MEASURE:VPP] <value><NL>
Where: <value> ::= exponential, voltage peak to peak

:MEASure:VRELative

Command :MEASURE:VRELATIVE <percent_argument>
Query :MEASURE:VRELATIVE?
Returned Format [:MEASURE:VRELATIVE] <percent_argument><NL>
Where: <percent_argument> ::= integer, Vmarker2 relative position in percent, from 0 through 100

:MEASure:VSTArt

Command :MEASURE:VSTART <vstart_argument>
Query :MEASURE:VSTART?
Returned Format [:MEASURE:VSTART] <vstart_argument><NL>
Where: <vstart_argument> ::= exponential, voltage at y1marker

:MEASure:VSTOP

Command :MEASURE:VSTOP <vstop_argument>
Query :MEASURE:VSTOP?
Returned Format [:MEASURE:VSTOP] <vstop_argument><NL>
Where: <vstop_argument> ::= exponential, voltage at y2marker

:MEASure:VTIMe?

Query :MEASURE:VTIME? <vtimme_argument>
Returned Format [:MEASURE:VTIMMe] <voltage><NL>
Where: <vtimme_argument> ::= real number representing the displayed time from the trigger in seconds
<voltage> ::= exponential, voltage at specified time

Programmer's Quick Reference Guide

:MEASure:VTOP

Command :MEASure:VTOP
Query :MEASure:VTOP?
Returned Format [:MEASure:VTOP] <value><NL>
Where: <value> ::= exponential, voltage at the top of the waveform

:MEASure:WCOMpare:ALLOWance

Command :MEASure:WCOMpare:ALLOWance <allow_argument>
Query :MEASure:WCOMpare:ALLOWance?
Returned Format [:MEASure:WCOMpare:ALLOWance] <allow_argument><NL>
Where: <allow_argument> ::= real number representing number of vertical divisions of allowance, from 0.0 to 8.0

:MEASure:WCOMpare:COMPARE

Command :MEASure:WCOMpare:COMPARE {CHANnel<n> | FUNCTION{1 | 2 | 3 | 4}, WMMemory{1 | 2 | 3 | 4}}
Query :MEASure:WCOMpare:COMPARE?
Returned Format [:MEASure:WCOMpare:COMPARE] {CHANnel<n> | FUNCTION{1 | 2 | 3 | 4}, WMMemory{1 | 2 | 3 | 4}}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

:MEASure:WCOMpare:DESTination

Command :MEASure:WCOMpare:DESTination
<source_argument>, <destination_argument>
Query :MEASure:WCOMpare:DESTination? {CHANnel<n> | FUNCTION{1 | 2 | 3 | 4} | SCreen}
Returned Format [:MEASure:WCOMpare:DESTination] {CHANnel<n> | {FUNCTION{1 | 2 | 3 | 4} | SCreen}} {WMMemory{1 | 2 | 3 | 4} | PMEMory{1 | 2} | MULTiple | OFF}<NL>
Where: <source_argument> ::= {{SCreen, {OFF | PMEMory{1 | 2}}}} | {{CHANnel<n> | FUNCTION{1 | 2 | 3 | 4}}}
<destination_argument> ::= {WMMemory{1 | 2 | 3 | 4} | MULTiple | PMEMory{1 | 2} | OFF}
<n> ::= integer, 1 or 2 (HP 54520C/54522C) or 1 through 4 (HP 54540C/54542C)

:MEASure:WCOMpare:HALLowance

Command	:MEASure:WCOMpare:HALLowance <allow_argument>
Query	:MEASure:WCOMpare:HALLowance?
Returned Format	[:MEASure:WCOMpare:HALLowance] <allow_argument><NL>
Where:	<allow_argument> ::= real number representing number of horizontal divisions of allowance, from 0.0 to 8.0

:MEASure:WCOMpare:POSTfailure

Command	:MEASure:WCOMpare:POSTfailure {CONTinue STOP}
Query	:MEASure:WCOMpare:POSTfailure?
Returned Format	[:MEASure:WCOMpare:POSTfailure] {CONTinue STOP}<NL>

:MEASure:WCOMpare:VALLowance

Command	:MEASure:WCOMpare:VALLowance <allow_argument>
Query	:MEASure:WCOMpare:VALLowance?
Returned Format	[:MEASure:WCOMpare:VALLowance] <allow_argument><NL>
Where:	<allow_argument> ::= real number representing number of vertical divisions of allowance, from 0.0 to 8.0

:MEASure:WCOMpare:WTEST

Command	:MEASure:WCOMpare:WTEST {MEASure OFF}
Query	:MEASure:WCOMpare:WTEST?
Returned Format	[:MEASure:WCOMpare:WTEST] {MEASure OFF}<NL>

:MENU

Command	:MENU {CHANnel<n>TIMEbase TRIGger DISK DISPLAY DELTA MATH SAVE MEASure UTILITY SHOW}
Query	:MENU?
Returned Format	[:MENU] {CHANnel<n>TIMEbase TRIGger DISK DISPLAY DELTA MATH SAVE MEASure UTILITY SHOW}
Where:	<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

Programmer's Quick Reference Guide

:MERGe

Command :MERGe <pmemory_num>
Where: <pmemory_num> ::= integer, 1 or 2

:MMEMory:DISPlay

Command :MMEMory:DISPlay {{OFF | 0} | {ON | 1}}
Query :MMEMory:DISPlay?
Returned Format [:MMEMory:DISPlay] {0 | 1}<NL>

:MMEMory:FNUMber

Command :MMEMory:FNUMber <failure_number>
Query :MMEMory:FNUMber?
Returned Format [:MMEMory:FNUMber] <failure_number><NL>
Where: <failure_number> ::= integer, 0 to 665

:MMEMory:SOURce

Command :MMEMory:SOURce {CHANnel<n> | FUNCTion{1 | 2 | 3 | 4}}
Query :MMEMory:SOURce?
Returned Format [:MMEMory:SOURce] {CHANnel<n> | FUNCTion{1 | 2 | 3 | 4}}<NL>
Where: <n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:MMEMory:STORe

Command :MMEMory:STORe {WMEMory{1 | 2 | 3 | 4}}

:PCFREquency

Command :PCFREquency <cal_freq>
Query :PCFREquency
Returned Format [:PCFREquency] <cal_freq>
Where: <cal_freq> ::= exponential, probe compensation signal
frequency in hertz

:PLOT

Query :PLOT?

:PMEMory{1 | 2}:CLEar

Command :PMEMory{1 | 2}:CLEar

:PMEMory{1 | 2}:DISPlay

Command :PMEMory{1 | 2}:DISPLAY {{OFF | 0} | {ON | 1}}
Query :PMEMory{1 | 2}:DISPLAY?
Returned Format [:PMEMory{1 | 2}:DISPLAY] {0 | 1}<NL>

:PMEMory{1 | 2}:MERGe

Command :PMEMory{1 | 2}:MERGe

:PMEMory{1 | 2}:SETup?

Query :PMEMory{1 | 2}:SETup?
Returned Format PMEMory{1 | 2}:DISP{0 | 1}<NL>

:PLOT?

Query :PLOT?

:POWerup{RUNning | STOPped}

Command :POWerup{RUNning | STOPped}
Query :POWerup?
Returned Format [:POWerup] {STOPped | RUNning}

Programmer's Quick Reference Guide

:PRINT?

Query :PRINT?

:RUN

Command :RUN

:SEQUENTIAL:DISPLAY

Command :SEQUENTIAL:DISPLAY {{OFF | 0} | {ON | 1}}
Query :SEQUENTIAL:DISPLAY?
Returned Format [:SEQUENTIAL:DISPLAY] {0 | 1}<NL>

:SEQUENTIAL:EXCLUDE

Command :SEQUENTIAL:EXCLUDE <from_argument>,<to_argument>
Query :SEQUENTIAL:EXCLUDE?
Returned Format [:SEQUENTIAL:EXCLUDE] <exclude_list><NL>
Where: <from_argument> ::= integer, segment number of the lower end
of the exclude range
<to_argument> ::= integer, segment number of the upper end
of the exclude range
number greater than or equal to the value of <from_argument>
<exclude_list> ::= integer, a list of previously captured
segment numbers separated by commas

:SEQUENTIAL:INCLUDE

Command :SEQUENTIAL:INCLUDE <from_argument>,<to_argument>
Query :SEQUENTIAL:INCLUDE?
Returned Format [:SEQUENTIAL:INCLUDE] <include_list><NL>
Where: <from_argument> ::= integer, segment number of the lower end
of the include range
<to_argument> ::= integer, segment number of the upper end
of the include range
<include_list> ::= integer, a list of previously captured
segment numbers separated by commas

:SEQUENTIAL:NPOints

Command :SEQUENTIAL:NPOints <points_argument>
Query :SEQUENTIAL:NPOints?
Returned Format [:SEQUENTIAL:NPOints] <points_argument><NL>
Where: <points_argument> ::= integer, 4 to 32768

:SEQUENTIAL:NSEGments

Command :SEQUENTIAL:NSEGments <segments_argument>
Query :SEQUENTIAL:NSEGments?
Returned Format [:SEQUENTIAL:NSEGments] <segments_argument><NL>
Where: <segments_argument> ::= integer, 1 to 8888 dependent on the
SEQUENTIAL:NPOints selection

:SEQUENTIAL:SETUp?

Query :SEQUENTIAL:SETUp?
Returned Format :SEQ:DISP {0 | 1};
Where: EXCL <exclude_list>;
INCL <include_list>;
NPO <points_argument>;
NSEG <segment_argument>;
SNUM <segments_argument>; (Sequential Single Shot Mode Only)
SOURce CHANnel<n><NL> (Sequential Single Shot Mode Only)
<exclude_list> ::= integer, a list of previously captured
segment numbers separated by commas
<include_list> ::= integer, a list of previously captured
segment numbers separated by commas
<points_argument> ::= integer, 4 to 32768
<segments_argument> ::= integer, 1 to 8888 dependent on the
points selected
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:SEQuential:SNUMber

Command :SEQuential:SNUMber <segments_argument>
Query :SEQuential:SNUMber?
Returned Format [:SEQuential:SNUMber] <segments_argument><NL>
Where: <segments_argument> ::= integer, 1 to 8888 dependent on the
number of segments acquired and ACQuire:TYPE currently
selected

:SEQuential:SOURce

Command :SEQuential:SOURce {CHANnel<n>}
Query :SEQuential:SOURce?
Returned Format [:SEQuential:SOURce] {CHANnel<n>}<NL>
Where: <n> ::= integer 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:SEQuential:TTAGs?

Query :SEQuential:TTAGs? <segments_argument>
Where: <segments_argument> ::= integer, 1 to 8888 dependent on the
SEQuential:NSEGments selection

:SEQuential:TTDifference?

Query :SEQuential:TTDifference?
Where: <segments_argument>,<segments_argument>
<segments_argument> ::= integer, 1 to 8888 dependent on the
SEQuential:NSEGments selection

:SERial

Command :SERial <serial_number>
Where: <serial_number> ::= 10 character serial number within quotes

:STATUs?

Query :STATUs? <display>
Returned Format [:STATUs] {0 | 1}<NL>
Where: <display> ::= {CHANnel<n> | FUNCtion{1 | 2 | 3 | 4} |
WMEMory{1 | 2 | 3 | 4} | PMEMory{1 | 2}<NL>
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:STOP

Command :STOP

:STORe

Command :STORe <source>,<destination>
Where: <source> ::= {CHANnel<n> | FUNCtion{1 | 2 | 3 | 4} |
WMEMory{1 | 2 | 3 | 4}}
<destination> ::= {WMEMory{1 | 2 | 3 | 4}}
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:SYSTem:DATE

Command :SYSTem:DATE <year>,<month>,<day>
Query :SYSTem:DATE?
Returned Format [:SYSTem:DATE] "DDMMYYYY"<NL>
Where: <year>/<YYYY> ::= integer, 1990 through 2059
<month> ::= integer, 1 through 12
<MMM> ::= three digit alphabetic month
<day>/<DD> ::= integer, 1 through 31

:SYSTem:DSP

Command :SYSTem:DSP <ascii_string>
Query :SYSTem:DSP?
Returned Format [:SYSTem:DSP] <ascii_string><NL>
Where: <ascii_string> ::= string response data containing the last
information written on the advisory line

:SYSTem:ERRor?

Query :SYSTem:ERRor [{NUMBER | STRing}]
Returned Format [:SYSTem:ERRor] <error>[,<ascii_string>]<NL>
Where: <error> ::= an integer error code
<ascii_string> ::= an alpha string specifying the error condition

:SYSTem:HEAder

Command :SYSTem:HEADER {{OFF | 0} | {ON | 1}}
Query :SYSTem:HEADER?
Returned Format [:SYSTem:HEADER] {0 | 1}<NL>

:SYSTem:KEY

Command :SYSTem:KEY <key_code>
Query :SYSTem:KEY?
Returned Format [:SYSTem:KEY] <key_code><NL>
Where: <key_code> ::= integer, 0 through 63

:SYSTem:LONGform

Command :SYSTem:LONGform {{OFF | 0} | {ON | 1}}
Query :SYSTem:LONGform?
Returned Format [:SYSTem:LONGform] {0 | 1}<NL>

:SYSTem:PIMacro

Command :SYSTem:PIMacro <ascii_string>
Where: <ascii_string> ::= name of the defined macro

:SYSTem:SETUp

Command :SYSTem:SETUp <block_data>
Query :SYSTem:SETUp?
Returned Format [:SYSTem:SETUp] <block_data><NL>
Where: <block_data> ::= #800002048<setup_string>
<setup_string> ::= block of binary data bytes

:SYSTem:TIME

Command :SYSTem:TIME <hour>,<minute>,<second>
Query :SYSTem:TIME?
Returned Format [:SYSTem:TIME] "HH:MM:SS"<NL>
Where: <hour>/<HH> ::= integer, 0 through 23
<month>/<MM> ::= integer, 0 through 59
<second>/<SS> ::= integer, 0 through 59

:SYSTem:UTILITY

Command :SYSTem:UTILITY:GMARKers {ON | OFF}
:SYSTem:UTILITY:LABels {ON | OFF}
:SYSTem:UTILITY:FACTOr {ON | OFF}
:SYSTem:UTILITY:FPANEL {ON | OFF}
:SYSTem:UTILITY:FPANEL:TIMEout {<timeout> | INFINITY}
Query :SYSTem:UTILITY:GMARKers?
:SYSTem:UTILITY:LABels?
:SYSTem:UTILITY:FACTOr?
:SYSTem:UTILITY:FPANEL?
:SYSTem:UTILITY:FPANEL:TIMEout?
Returned Format [:SYSTem:UTILITY:GMARKers] {ON | OFF}<NL>
Where: <timeout> ::= integer, 0 through 12 (hours)

:TER?

Query :TER?
Returned Format [:TER] {0 | 1}<NL>

Programmer's Quick Reference Guide

:TIMEbase:DElay

Command :TIMEbase:DElay <delay_value>
Query :TIMEbase:DElay?
Returned Format [:TIMEbase:DElay] <delay_value><NL>
Where: <delay_value> ::= exponential, time from trigger to display
reference in seconds

:TIMEbase:MODE

Command :TIMEbase:MODE {AUTO | TRIGGERed | SINGLE}
Query :TIMEbase:MODE?
Returned Format [:TIMEbase:MODE] {AUTO | TRIGGERed | SINGLE}<NL>

:TIMEbase:RANGE

Command :TIMEbase:RANGE <range_value>
Query :TIMEbase:RANGE?
Returned Format [:TIMEbase:RANGE] <range_value><NL>
Where: <range_value> ::= exponential, 10 ns to 50 s in a 1,2,5
sequence

:TIMEbase:REFERENCE

Command :TIMEbase:REFERENCE {LEFT | CENTER | RIGHT}
Query :TIMEbase:REFERENCE?
Returned Format [:TIMEbase:REFERENCE] {LEFT | CENTER | RIGHT}<NL>

:TIMEbase:RLENGTH

Command :TIMEbase:RLENGTH <length_argument>
Query :TIMEbase:RLENGTH?
Returned Format [:TIMEbase:RLENGTH] <length_argument><NL>
Where: <length_argument> ::= integer, 500 in the repetitive mode,
512, 1024, 2048, 4196, 8192, 16384, or 32768 in the
real-time mode (sequential off), or 4 to 32768 in the
real-time mode (sequential on), depending on the current
:SEQUENTIAL:NSEGMENTS value

:TIMEbase:SAMPLE

Command	<code>:TIMEbase:SAMPLE {REALtime REPetitive}</code>
Query	<code>:TIMEbase:SAMPLE?</code>
Returned Format	<code>[:TIMEbase:SAMPLE] {REALtime REPetitive}<NL></code>

:TIMEbase:SAMPLE:CLOCK

Command	<code>:TIMEbase:SAMPLE:CLOCK {AUTO <clock_value>}</code>
Query	<code>:TIMEbase:SAMPLE:CLOCK?</code>
Returned Format	<code>[:TIMEbase:SAMPLE:CLOCK] <clock_value><NL></code>
Where:	<code><clock_value> ::= exponential, 10S/s to 2GS/s</code>

:TIMEbase:SETup?

Query	<code>:TIMEbase:SETup?</code>
Returned Format	<code>:TIME:DEL <delay_value>; MODE {AUTO TRIG SING}; RANGe <range_value>; RLEN <length_argument>; REF {LEFT CENT RIGH}; SAMPLE {REAL REP}; SAMP:CLOC {AUTO <clock_value>}<NL></code>
Where:	<code><delay_value> ::= exponential, time from trigger to display reference in seconds <range_value> ::= exponential, 5ns to 50s <length_argument> ::= 500 in the repetitive mode, 512, 1024, 2048, 4196, 8192, 16384, or 32768 in the real-time mode (sequential off), or 4 to 32768 in the real-time mode (sequential on), depending on the current :SEQUENTIAL:NSEGments value <clock_value> ::= exponential, 10S/s to 2GS/s</code>

:TRIGGER:CENTERed

Command	<code>:TRIGGER:CENTERed</code>
----------------	--------------------------------

:TRIGger:CONDition

Command	<code>:TRIGger:CONDition {ENTER EXIT TRUE FALSE GT,<gt_argument> LT,<lt_argument> RANGE,<range_gt>,<range_lt>}</code>
Query	<code>:TRIGger:CONDition?</code>
Returned Format	<code>[:TRIGger:CONDition] <argument><NL></code>
Where:	<p><code><argument> ::= {ENTER EXIT GT,<gt_argument> LT,<lt_argument> RANGE,<range_gt>,<range_lt>} in PATTERN or DELay with QUALify:PATTERn selected; {TRUE FALSE} (in STATE or DELay with QUALify:STATE selected; or RANGE, <range_gt>,<range_lt> in TV mode)</code></p> <p><code><gt_argument> ::= exponential, 20 ns to 160 ms</code></p> <p><code><lt_argument> ::= exponential, 20 ns to 160 ms</code></p> <p><code><range_gt> ::= exponential, 20 ns to 159.999 ms (must be less than <range_lt>)</code></p> <p><code><range_lt> ::= exponential, 30 ns to 160 ms (must be greater than <range_gt>)</code></p>

:TRIGger:COUPling

Command	<code>:TRIGger:COUPling {AC DC LFReject}</code>
Query	<code>:TRIGger:COUPling?</code>
Returned Format	<code>[:TRIGger:COUPling] {AC DC LFReject}<NL></code>

:TRIGger:DELay

Command	<code>:TRIGger:DELay {TIME,<time_argument> EVENT,<event_argument>}</code>
Query	<code>:TRIGger:DELay?</code>
Returned Format	<code>[:TRIGger:DELay] {TIME,<time_argument> EVENT,<event_argument>}<NL></code>
Where:	<p><code><time_argument> ::= exponential, amount of delay from 30 ns to 160 ms</code></p> <p><code><event_argument> ::= integer, number of events from 1 to 16000000</code></p>

:TRIGger:DELay:SLOPe

Command	:TRIGGER:DELay:SLOPe {POSitive NEGative}
Query	:TRIGGER:DELay:SLOPe?
Returned Format	[:TRIGGER:DELay:SLOPe] {POSitive NEGative}<NL>

:TRIGger:DELay:SOURce

Command	:TRIGGER:DELay:SOURce {CHANnel<n> EXTernal}
Query	:TRIGGER:DELay:SOURce?
Returned Format	[:TRIGGER:DELay:SOURce] {CHANnel<n> EXTernal}
Where:	<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

NOTE: EXTERNAL available only on HP 54520C/54522C

:TRIGger:FIELD

Command	:TRIGGER:FIELD {1 2}
Query	:TRIGGER:FIELD?
Returned Format	[:TRIGGER:FIELD] {1 2}<NL>

:TRIGger:GLITch:CENTERed

Command	:TRIGGER:GLITCH:CENTERed
---------	--------------------------

:TRIGger:GLITch:HOLDoff

Command	:TRIGGER:GLITCH:HOLDoff <holdoff_time>
Query	:TRIGGER:GLITCH:HOLDoff?
Returned Format	[:TRIGGER:GLITCH:HOLDoff] <holdoff_time><NL>
Where:	<holdoff_time> ::= exponential, 40 ns to 320 ms rounded to nearest 20 ns increment

:TRIGger:GLITch:LEVel

Command :TRIGger:GLITch:LEVel <level_argument>
Query :TRIGger:GLITch:LEVel?
Returned Format [:TRIGger:GLITch:LEVEL] <level_argument><NL>
Where: <level_argument> ::= exponential, for internal triggers, ± 1.5
x
full-scale voltage from center screen, for external
triggers
(HP 54520C/54522C) ± 2 volts with probe attenuation at 1:1

:TRIGger:GLITch:SOURce

Command :TRIGger:GLITch:SOURce {CHANnel<n> | EXTernal}, {HIGH | LOW}
Query :TRIGger:GLITch:SOURCE?
Returned Format [:TRIGger:GLITch:SOURce] {CHANnel<n> | EXTernal}, {HIGH | LOW}
Where: <n> ::= integer 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)
NOTE: EXTernal available only on HP 54520C/54522C

:TRIGger:GLITch:WIDth

Command :TRIGger:GLITch:WIDth {GT | LT}, <width_argument>
Query :TRIGger:GLITch:WIDth?
Returned Format [:TRIGger:GLITch:WIDTH] {GT | LT}, <width_argument><NL>
Where: <width_argument> ::= exponential, 5 ns to 160 ms

:TRIGger:HOLDoff

Command :TRIGger:HOLDoff {{TIME,<holdoff_time>} |
{EVENT,<event_argument>}}
Query :TRIGger:HOLDoff?
Returned Format [:TRIGger:HOLDoff] {TIME,<holdoff_value>} |
{EVENT,<event_argument>}<NL>
Where: <holdoff_time> ::= exponential, 40 ns to 320 ms
<event_argument> ::= integer, 1 to 16000000

:TRIGger:LEVel

Command	:TRIGger:LEVel <level_argument>
Query	:TRIGger:LEVel?
Returned Format	[:TRIGger:LEVel] <level_argument><NL>
Where:	<level_argument> ::= for internal triggers, $\pm 1.5 \times$ full-scale voltage from center screen; for external triggers, ± 2 volts with probe attenuation at 1:1

:TRIGger:LINE

Command	:TRIGger:LINE <line_number>
Query	:TRIGger:LINE?
Returned Format	[:TRIGger:LINE] <line_number><NL>
Where:	<line_number> ::= integer, 1 to 625 (depends on STANDARD and FIELD selection)

:TRIGger:LOGic

Command	:TRIGger:LOGic {HIGH LOW DONTcare}
Query	:TRIGger:LOGic?
Returned Format	[:TRIGger:LOGic] {HIGH LOW DONTcare}<NL>

:TRIGger:MODE

Command	:TRIGger:MODE {EDGE PATTern STATE DELay TV GLITch}
Query	:TRIGger:MODE?
Returned Format	[:TRIGger:MODE] {EDGE PATTern STATE DELay TV GLITch}<NL>

:TRIGger:NREJect

Command	:TRIGger:NREJect {{OFF 0} {ON 1}}
Query	:TRIGger:NREJect?
Returned Format	[:TRIGger:NREJect] {0 1}<NL>

Programmer's Quick Reference Guide

:TRIGger:OCCurrence

Command	:TRIGger:OCCurrence <occurrence_argument>
Query	:TRIGger:OCCurrence?
Returned Format	[:TRIGger:OCCurrence] <occurrence_argument><NL>
Where:	<occurrence_argument> ::= integer, 1 to 16000000

:TRIGger:OCCurrence:SLOPe

Command	:TRIGger:OCCurrence:SLOPe {POSitive NEGative}
Query	:TRIGger:OCCurrence:SLOPe?
Returned Format	[:TRIGger:OCCurrence:SLOPe] {POSitive NEGative}<NL>

:TRIGger:OCCurrence:SOURce

Command	:TRIGger:OCCurrence:SOURce {CHANnel<n> EXTernal}
Query	:TRIGger:OCCurrence:SOURce?
Returned Format	[:TRIGger:OCCurrence:SOURce] {CHANnel<n> EXTernal}<NL>
Where:	<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

NOTE: EXTernal available only on HP 54520C/54522C

:TRIGger:PATH

Command	:TRIGger:PATH {CHANnel<n> EXTernal}
Query	:TRIGger:PATH?
Returned Format	[:TRIGger:PATH] {CHANnel<n> EXTernal}<NL>
Where:	<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4 (HP 54540C/54542C)

NOTE: EXTernal available only on HP 54520C/54522C

:TRIGger:POLarity

Command	:TRIGger:POLarity {POSitive NEGative}
Query	:TRIGger:POLarity?
Returned Format	[:TRIGger:POLarity] {POSitive NEGative}<NL>

:TRIGger:QUALify

Command	<code>:TRIGger:QUALify {{EDGE PATTern STATE} {LOW HIGH}}</code>
Query	<code>:TRIGger:QUALify?</code>
Returned Format	<code>[:TRIGger:QUALify] {{EDGE PATTern STATE} {LOW HIGH}}<NL></code>

:TRIGger:SETup?

Query	<code>:TRIGger:SETup?</code>
Returned Format	<code>:TRIG:MODE EDGE;</code> <code>COUP {AC DC LFR};</code> <code>HOLD {{TIME,<holdoff_time>} EVENT, <event_argument>});</code> <code>LEV <level_argument>;</code> <code>NREQ {0 1};</code> <code>SLOP {POS NEG};</code> <code>SOUR {CHAN<n> EXT LINE AUX}<NL> (EXT is only valid for the 54520/22)</code>
	<code>:TRIG:MODE PATT;</code>
	<code>COND {ENT EXIT GT,<gt_argument> LT,<lt_argument> RANG,<range_gt>,<range_lt>};</code> <code>HOLD {{TIME,<holdoff_time>} EVEN, <event_argument>});</code> <code>LEV <level_argument>;</code> <code>LOG {HIGH LOW DONT};</code> <code>NREQ {0 1};</code> <code>PATH {CHAN<n> EXT}<NL> (EXT is only valid for the 54520/22)</code>
	<code>:TRIG:MODE STAT;</code>
	<code>COND {TRUE FALS};</code> <code>HOLD {{TIME,<holdoff_time>} {EVEN, <event_argument>});</code> <code>LEV <level_argument>;</code> <code>LOG {HIGH LOW DONT};</code> <code>NREQ {0 1};</code> <code>PATH {CHAN<n> EXT}; (EXT is only valid for the 54520/22)</code> <code>SLOP {POS NEG};</code> <code>SOUR {CHAN<n> EXT}<NL> (EXT is only valid for the 54520/22)</code>

Programmer's Quick Reference Guide

```
:TRIG:MODE DEL;
COND {ENT | EXIT | TRUE | FALS | GT,<gt_argument> |  
LT,<lt_argument> | RANG,<range_gt>,<range_lt>};
DEL {{TIME,<time_value>} | {EVEN, <event_value>}};
DEL:SLOP {POS | NEG};
DEL:SOUR {CHAN<n> | EXT};    (EXT is only valid for the 54520/22)
LEV <level_arguments>;
LOG {HIGH | LOW | DONT};
NREJ {0 | 1};
OCC <occurrence_argument>;
OCC:SLOP {POS | NEG};
OCC:SOUR {CHAN<n> | EXT};    (EXT is only valid for the 54520/22)
PATH {CHAN<n> | EXT};    (EXT is only valid for the 54520/22)
QUAL {EDGE | PATT | STAT};
SLOP {POS | NEG};
SOUR {CHAN<n> | EXT}<NL>  (EXT is only valid for the
54520/22)

:TRIG:MODE TV;
COND {RANG,<range_gt>,<range_lt>};
FIEL {1 | 2};
HOLD {{TIME,<holdoff_time>} | {EVEN, <event_argument>}};
LEV <level_argument>;
LINE <line_number>;
NREJ {0 | 1};
OCC <occurrence_argument>;
OCC:SLOP {POS | NEG};
POL {POS | NEG};
QUAL {LOW | HIGH};
SOUR {CHAN<n> | EXT};    (EXT is only valid for the 54520/22)
STAN {525 | 625 | USER}<NL>

:TRIG:MODE GLIT;
GLITch:HOLD TIME,<holdoff_time>;
GLITch:LEV <level_argument>;
GLITch:NREJ {0 | 1};
GLITch:SOUR {CHAN<n> | EXT}, {LOW | HIGH};    (EXT is only valid
for the 54520/22)
GLITch:WIDth {GT | LT}, <width_argument><NL>
```

Where:

```
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4  
      (HP 54540C/54542C)  
<gt_argument> ::= exponential, 20 ns to 160 ms  
<lt_argument> ::= exponential, 20 ns to 160 ms  
<range_gt> ::= exponential, 20 ns to 159.999 ms (must be less  
      than <range_lt>)  
<range_lt> ::= exponential, 30 ns to 160 ms (must be greater  
      than <range_gt>)  
<time_value> ::= exponential, amount of delay from 30ns to  
      160ms  
<event_value> ::= integer, number of events from 1 to 16000000  
<holdoff_time> ::= exponential, 40 ns to 320 ms rounded to  
      nearest 20 ns increment  
<level_argument> ::= exponential, trigger level in volts  
<width_argument> ::= exponential, 5 ns to 160 ms  
<event_argument> ::= integer, 1 to 16000000  
<line_number> ::= integer, 1 to 625 (depends on STANDARD and  
      FIELD selection)
```

:VIEW

Command :VIEW <display>
Where: <display> ::=CHANnel<n>|FUNCTION{1 | 2 | 3 | 4} |
 PMEMory{1 | 2} | WMEMory{1 | 2 | 3 | 4}
<n> ::= integer, 1 or 2 (HP 54520C/54522C), or 1 through 4
 (HP 54540C/54542C)
<n> ::= integer 1 or 2 (HP 54520C/54522C)

:WAveform:DATA

Command :WAveform:DATA <block_data>
Query :WAveform:DATA?
Returned Format [:WAveform:DATA] <block_data><NL>
Where: <block_data> ::= definite block data in IEEE 488.2 # format

:WAveform:FORMAT

Command :WAveform:FORMAT {ASCII | WORD | BYTE | COMPressed}
Query :WAveform:FORMAT?
Returned Format [:WAveform:FORMAT] {ASCII | WORD | BYTE | COMPressed}<NL>

:WAveform:POINTs

Query :WAveform:POINTs?
Returned Format [:WAveform:POINTs] {512 | 1024 | 2048 | 4096 | 8192 | 16384 |
32768}<NL>

:WAveform:PREamble

Command :WAveform:PREamble <preamble_data>
Query :WAveform:PREamble?
Returned Format [:WAveform:PREamble] <preamble block><NL>
Where: <preamble_data> ::= <format NR1>, <type NR1>, <points NR1>, <count NR1>, <xincrement NR3>, <xorigin NR3>, <xreference NR1>, <yincrement NR3>, <yorigin NR3>, <yreference NR1>
<format> ::= 0 for ASCII format
1 for BYTE format
2 for WORD format
4 for COMPRESSED format
<type> ::= 0 for INVALID type
1 for NORMAL type or REALTIME
2 for AVERAGE type
3 for ENVELOPE type
4 for RAWDATA type
5 for PDETect type

:WAveform:SOURce

Command :WAveform:SOURce {CHANnel<n> | WMMemory{1 | 2 | 3 | 4}}
Query :WAveform:SOURce?
Returned Format [:WAveform:SOURce] {CHANnel<n> | WMMemory{1 | 2 | 3 | 4}}<NL>
Where: <n> ::= integer 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:WAveform:TYPE?

Query :WAveform:TYPE?
Returned Format [:WAveform:TYPE] {INValid | AVERage | ENVelope | NORMal |
PDETect | RAWData}<NL>

:WAveform:XINCrement?

Query :WAveform:XINCrement?
Returned Format [:WAveform:XINCrement] <value><NL>
Where: <value> ::= exponential, x-increment in the current preamble

Programmer's Quick Reference Guide

:WAVeform:XORigin?

Query :WAVeform:XORigin?
Returned Format [:WAVeform:XORigin] <value>[,<value>]...<NL>
Where: <value> ::= exponential, x-origin value in the current preamble

:WAVeform:XREFerence?

Query :WAVeform:XREFerence?
Returned Format [:WAVeform:XREFerence] <value><NL>
Where: <value> ::= integer, x-reference value in the current preamble

:WAVeform:YINCrement?

Query Syntax: :WAVeform:YINCrement?
Returned Format [:WAVeform:YINCrement] <value><NL>
Where: <value> ::= exponential, y-increment value in the current preamble

:WAVeform:YORigin?

Query :WAVeform:YORigin?
Returned Format [:WAVeform:YORigin] <value><NL>
Where: <value> ::= exponential, y-origin in the current preamble

:WAVeform:YREFerence?

Query :WAVeform:YREFerence?
Returned Format [:WAVeform:YREFerence] <value><NL>
Where: <value> ::= integer, y-reference value in the current preamble

:WMEMory{1|2|3|4}:DISPlay

Command :WMEMory{1 | 2 | 3 | 4}:DISPlay {{OFF | 0} | {ON | 1}}
Query :WMEMory{1 | 2 | 3 | 4}:DISPlay?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:DISPlay] {0 | 1}<NL>

:WMEMory{1|2|3|4}:GET

Command :WMEMory{1 | 2 | 3 | 4}:GET {CHANnel<n> |
Where: WMEMory{1 | 2 | 3 | 4} | FUNCTION{1 | 2 | 3 | 4})}
<n> ::= integer 1 or 2 (HP 54520C/54522C), or 1 through 4
(HP 54540C/54542C)

:WMEMory{1|2|3|4}:PROTect

Command :WMEMory{1 | 2 | 3 | 4}:PROTect {{OFF | 0} | {ON | 1}}
Query :WMEMory{1 | 2 | 3 | 4}:PROTect?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:PROTect] {0 | 1}<NL>

:WMEMory{1|2|3|4}:SETup?

Query :WMEMory{1 | 2 | 3 | 4}:SETup?
Returned Format :WMEM{1 | 2 | 3 | 4}:DISP {0 | 1};
PROT {0 | 1};
XOFF <offset_argument>;
XRANG <range_argument>;
YOFF <yoffset>;
YRANG <yrange><NL>
Where: <range_argument> ::= exponential, 5 ns to 50 sec
<offset_argument> ::= exponential, time from trigger to
display reference in seconds
<yoffset> ::= exponential, offset value in volts
<yrange> ::= exponential, full-scale range value

:WMEMory{1|2|3|4}:XOFFSET

Command :WMEMory{1 | 2 | 3 | 4}:XOFFSET <xoffset_argument>
Query :WMEMory{1 | 2 | 3 | 4}:XOFFSET?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:XOFFSET] <xoffset_argument><NL>
Where: <xoffset_argument> ::= exponential, time from trigger to the
on screen delay reference point. The maximum value
depends on the :WMEMory:XRANGE setting

:WMEMory{1|2|3|4}:XRANge

Command :WMEMory{1 | 2 | 3 | 4}:XRANge <range_argument>
Query :WMEMory{1 | 2 | 3 | 4}:XRANge?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:XRANge] <range_argument><NL>
Where: <range_argument> ::= exponential, 5 ns to 50 s in a 1,2,5 sequence

:WMEMory{1|2|3|4}:YOFFset?

Query :WMEMory{1 | 2 | 3 | 4}:YOFFset?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:YOFFset] <yoffset><NL>
Where: <yoffset> ::= exponential, offset value in volts

:WMEMory{1|2|3|4}:YRANge?

Query :WMEMory{1 | 2 | 3 | 4}:YRANge?
Returned Format [:WMEMory{1 | 2 | 3 | 4}:YRANge] <yrange><NL>
Where: <yrange> ::= exponential, full-scale range value

© Copyright Hewlett-Packard Company 1993-1995
All Rights Reserved.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Document Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

Hewlett-Packard shall not be liable for errors contained herein or for damages in connection with the furnishing, performance, or use of this material.

Safety

This apparatus has been designed and tested in accordance with IEC Publication 348, Safety Requirements for Measuring Apparatus, and has been supplied in a safe condition. This is a Safety Class I instrument (provided with terminal for protective earthing). Before applying power, verify that the correct safety precautions are taken (see the following warnings). In addition, note the external markings on the instrument that are described under "Safety Symbols."

Warning

- Before turning on the instrument, you must connect the protective earth terminal of the instrument to the protective conductor of the (mains) power cord. The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. You must not negate the protective action by using an extension cord (power cable) without a protective conductor (grounding). Grounding one conductor of a two-conductor outlet is not sufficient protection.
- Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired fuses or short-circuited fuseholders. To do so could cause a shock or fire hazard.

• Service instructions are for trained service personnel. To avoid dangerous electric shock, do not perform any service unless qualified to do so. Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

- If you energize this instrument by an auto transformer (for voltage reduction), make sure the common terminal is connected to the earth terminal of the power source.

- Whenever it is likely that the ground protection is impaired, you must make the instrument inoperative and secure it against any unintended operation.

- Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

- Do not install substitute parts or perform any unauthorized modification to the instrument.

- Capacitors inside the instrument may retain a charge even if the instrument is disconnected from its source of supply.

- Use caution when exposing or handling the flat panel display. Handling or replacing the display shall be done only by qualified maintenance personnel.

Safety Symbols



Instruction manual symbol: the product is marked with this symbol when it is necessary for you to refer to the instruction manual in order to protect against damage to the product.



Hazardous voltage symbol.



Earth terminal symbol: Used to indicate a circuit common connected to grounded chassis.

WARNING

The Warning sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a Warning sign until the indicated conditions are fully understood and met.

CAUTION

The Caution sign denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond a Caution symbol until the indicated conditions are fully understood or met.

Product Warranty This Hewlett-Packard product has a warranty against defects in material and workmanship for a period of three years from date of shipment. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products that prove to be defective. For warranty service or repair, this product must be returned to a service facility designated by Hewlett-Packard. For products returned to Hewlett-Packard for warranty service, the Buyer shall prepay shipping charges to Hewlett-Packard and Hewlett-Packard shall pay shipping charges to return the product to the Buyer. However, the Buyer shall pay all shipping charges, duties, and taxes for products returned to Hewlett-Packard from another country. Hewlett-Packard warrants that its software and firmware designated by Hewlett-Packard for use with an instrument will execute its programming instructions when properly installed on that instrument. Hewlett-Packard does not warrant that the operation of the instrument software, or firmware will be uninterrupted or error free.	No other warranty is expressed or implied. Hewlett-Packard specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.	About this edition This is the first edition of the <i>HP 54520C and 54540C Series Oscilloscope Programmer's Quick Reference Guide</i> .	The following list of pages gives the date of the current edition and of any changed pages to that edition. All pages original edition
Exclusive Remedies The remedies provided herein are the buyer's sole and exclusive remedies. Hewlett-Packard shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.	Assistance Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products. For any assistance, contact your nearest Hewlett-Packard Sales Office.	 New editions are complete revisions of the manual. Update packages, which are issued between editions, contain additional and replacement pages to be merged into the manual by you. The dates on the title page change only when a new edition is published.	
Certification Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.	 A software or firmware code may be printed before the date. This code indicates the version level of the software or firmware of this product at the time the manual or update was issued. Many product updates do not require manual changes; and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one-to-one correspondence between product updates and manual updates.		
Limitation of Warranty The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.			